


6 OPERATING INSTRUCTIONS

6.1 USER INTERFACE

Operator interface includes:

- 1** Control panel;
- 2** Push-button panel;
- 3** Mobile control device.

Parts type and number changes in relation to machine configuration.



Control panel


NOTICE

The information regarding the programming and use of the control panel is given in the document INSTRUCTIONS B.


6 MACHINE OPERATING INSTRUCTIONS

Pushbutton panel

ID	DESCRIPTION	MORPHOLOGY	FUNCTION
1	EMERGENCY	Mushroom head push button (red)	Pressed: it immediately STOPS the machine
2	RESET	Backlighted push button (blue)	The flashing illumination of the indicator indicates the detection of one or more faults. <ul style="list-style-type: none"> When it is pressed for a few seconds it executes machine reset and alarms restoration (the machine is powered and the power units are restored). Blinking button goes off.
3	START CYCLE MANUAL	Lit push button (white)	Flashing light signals that button is active. <ul style="list-style-type: none"> Pressed simultaneously with "AB-Key" button starts the selected manual cycle. The button stays lit.
4	CYCLE STOPS	Black push button	Pressed: it allows machine timed STOPPAGE at the end of the movements in progress.
5	START CYCLE	Lit push button (white)	Pressed: it starts automatic cycle.
6	RELEASE GUARDS BLOWER	Lit push button (white)	When this key is pressed, it causes sending machine safety guard locks unlocking request. <ul style="list-style-type: none"> When light is STEADY, it indicates that safety guard is closed, but not locked (lockable). When light is OFF, it indicates that safety guard is closed and locked (unlockable). FAST flashing light indicates that the safety guard is being locked/unlocked. SLOW flashing light indicates that the button is active.
7	MACHINE MANAGEMENT	Key selector (2 positions)	It allows to select blow molding machine operation independently (STAND ALONE) or in combination with filling machine (COMBO). In COMBO mode, blow molding machine and filling machine automatic cycle start-up and stoppage are controlled respectively by buttons 12-13
8	OPERATION	Key selector (2 positions)	Used to define whether the machine is in "maintenance" mode (ON) or in "automatic" or "manual" mode (OFF).
9	AB-KEY	Lit push button (white)	Pressing this key enables different types of operations, activated only by pressing a second button, either this physical or represented on the operator interface. <ul style="list-style-type: none"> Selector switch 8 set to "ON": pressed at the same time with button 3, it starts the selected manual cycle. Selector switch 8 set to "OFF": pressed at the same time with button 3, it controls timed start-up of all blow molding machine axes. Selector switch 8 set to "OFF": pressed together with start-up button displayed in the pop-up window that appears on the screen, it commands the previously selected area to be started manually.



ID	DESCRIPTION	MORPHOLOGY	FUNCTION
10	TRANSPONDER KEY		By approaching this receiver, a "transponder" key allows you to automatically log in
11	FILLING MACHINE/ COMBO CYCLE STOPPAGE	Black push button	Pressed: It allows filling machine timed STOPPAGE at the end of the movements in progress. If selector switch 7 is turned to "COMBO" mode, it stops automatic cycle of both the filling machine and the blow molding machine at the end of the movements in progress.
12	FILLING MACHINE/ COMBO CYCLE START-UP	Lit push button (white)	Pressed: It STARTS machine functioning. If selector switch 7 is turned to "COMBO" mode, it starts automatic cycle of both the filling machine and the blow molding machine.
13	UNLOCKING FILLING MACHINE SAFETY GUARDS	Lit push button (white)	When this key is pressed, it causes sending machine safety guard locks unlocking request. <ul style="list-style-type: none"> When light is STEADY, it indicates that safety guard is closed, but not locked (lockable). When light is OFF, it indicates that safety guard is closed and locked (unlockable). FAST flashing light indicates that the safety guard is being locked/unlocked. SLOW flashing light indicates that the button is active.
14	FILLING MACHINE MAINTENANCE	Key selector (2 positions)	Used to define whether the machine is in "maintenance" mode (ON) or in "automatic" or "manual" mode (OFF).



6 MACHINE OPERATING INSTRUCTIONS

Mobile control device

The mobile control device (jog) is used for maintenance and/or size change-over operations at controlled and safe speed with safety guards open.

NOTICE


Adjustments are not allowed on moving parts, not even with the use of the mobile control device.

To activate the device, turn OPERATION selector switch on push-button panel to **SET-UP**.

Button **1** has three positions:

- fully released: operations are NOT allowed;
- intermediate position: running condition;
- fully pressed: panic emergency; reaching the panic position is seen as an anomaly and requires a reset.

Button **2** allows emergency stop.



NOTICE

The mobile control device operates, only if the dedicated safety guard is open.
Speed in jog mode cannot exceed 3% of maximum speed.

Devices location is indicated in the attached LAYOUT document.

6.2 RUN/STOP

See paragraph OPERATOR INTERFACE and the documents INSTRUCTIONS B for references to controls.

Run

If the safety and operating conditions are met:

- Press **RESET** key on push-button panel to enable safety guards locking and allow start-up.
- Press **CYCLE START** key on push-button panel to turn machine on.

Jog mode

If the safety and operating conditions are met:

- Select jog mode operation.
- Press **RESET** key on push-button panel to enable safety guards locking.
- Press **START** key on the mobile push-button panel to turn machine on.

Stop

- Wait until all the containers are out of the machine, then press **CYCLE STOP** key on push-button panel to stop the machine.

Emergency stop

The emergency stop that can be activated with the special buttons or by the display of fault messages that cause the machine to shut down. Deactivate the emergency stop button or identify and remove the cause of the activation of the safety device; clear the faults.

See the documents INSTRUCTIONS B for the description of the faults.

6.3 CLEANING

6.3.1 CLEANING WITH BROKEN BOTTLE/CONTAINER



Use adequate protective equipment (safety gloves, pliers, etc.), when filling glass bottles/containers.

- Stop the machine.
- Remove any residues of broken bottles/containers.
- Clean the machine base with a damp cloth and dry it with compressed air.
- Clean the sensors, photocells and reflectors delicately, making sure not to move or damage them.

6 MACHINE OPERATING INSTRUCTIONS

6.3.2 CIP WASHING

The machine is provided with a CIP washing device that is intended for washing and sanitizing the parts in contact with the filling liquid.

Types of washing:

- **RINSE ONLY:** consists of a simple washing with water;
- **SANITATION:** consists of a complete washing of the plant with the use of a washing product;
- **FLOODING:** consists of filling all machines with an appropriate cleaning solution to keep them clean during periods of inactivity (i.e. at night or on weekends). The filling can only be carried out after sanitizing the system.

SANITATION

The machine sanitation cycle is defined as the succession of stages of washing, rinsing and drainage in the manner and time required to ensure complete cleaning of the filler and the dramatic reduction of microbial load and varies depending on many parameters, such as the type of filled product, the type of plant, environmental conditions (higher temperatures require more frequent sanitations) modes of use of the filling line.

The sanitization cycles can be 3 steps (ref.1-3, usually used for frequent washing and sanitization cycles, occasionally alternated with 5 steps), 5 steps (ref.1-5, for more complete sanitization cycle services) or 7 steps (ref.1-7, for sanitization cycle services after bottling of more problematic products (i.e. milk-based)).

1. In the case of hot filling, it is necessary to perform initial rinsing at the temperature used for filling the product and then gradually decrease it until the mains temperature is reached. If the filling is cold, simply rinse at the mains temperature. This first rinse allows the elimination of most of the product residues from the piping and its duration will vary depending on the product that has been bottled previously (of course, if the product is water, rinsing will be very brief).
2. Carry out a cycle with soda (1.5%-2% at 80°-85°C) to permanently eliminate product residues left after rinsing.
3. Perform a rinse cycle with water at mains temperature until the soda (or acid) is completely eliminated.
4. Carry out a cycle with acid (usually nitric 1% at 30°C or phosphoric max 1% at 30°C) or with sanitizer (PAA-based chemical such as P3 -Oxonia or Divosan Mezzo).
5. Carry out a new cycle with soda (1.5%-2% at 80°-85°C).
6. Perform a cycle with sanitizer (PAA-based chemical such as P3 -Oxonia or Divosan Mezzo).
7. Once the cycle with acid or sanitizer has been completed, perform a final rinse with water at mains temperature. This rinse, usually the last to be carried out before the new production, will continue until acid or sanitizer value corresponds to that decided by the customer.

The following chart summarizes concentrations, temperatures and cycle duration of some products to be used for washing that can be used during sanitization. This chart is to be considered as a purely indicative and non-binding trace.

PRODUCTS for WASHING	CONCENTRATION	TEMPERATURE	DURATION expressed in minutes
Caustic Soda (NaOH)	2%	80 °C	30
Nitric Acid (HNO ₃)	1%	30 °C	20
phosphoric acid (H ₃ PO ₄)	1%	30 °C	20
PAA Solution	250 - 300 ppm	20 °C	20
Hot water		95°C	45

SAFETY INSTRUCTIONS

Dangerous substances (acids, soda, etc.) are used during sanitation cycles and dangerous temperatures are reached. Always take all appropriate precautions.

In the event of accidental contact with the sanitising products, rinse thoroughly with water or, if available, with detergent substances provided. In any case, immediately consult a doctor.

6.3.3 COP WASHING

The machine can be equipped with the COP washing system, which allows the machine to be washed externally automatically.

See OPERATOR INTERFACE paragraph and INSTRUCTIONS B documents for references to controls.

